



TG-3

GB Instructions for use
IEC countries



Warning

In case this appliance contains hydrocarbon refrigerant please refer to guidelines listed below.

As the appliance contains a flammable refrigerant, it is essential to ensure that the refrigerant pipes are not damaged.

Standard EN378 specifies that the room in which you install your appliance must have a volume of 1m³ per 8 g of hydrocarbon refrigerant used in the appliances. This is to avoid the formation of flammable gas/air mixtures in the room where the appliance is located in the event of a leak in the refrigerant circuit. The quantity of the refrigerant used in your appliance is indicated on the rating plate.

Warning:

Keep ventilation openings in the appliance's cabinet or in the built-in structure clear of obstruction

Do not use other **mechanical devices** or other means to accelerate the defrosting process than those recommended by the manufacturer

Do not damage the refrigerant system

Do not use **electrical appliances** inside the refrigerated storage compartment, unless they are of a type recommended by the manufacturer

Do not expose the appliance to rain

This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely. Young children should be supervised to ensure that they do not play with the appliance

Always keep the keys in a separate place and out of reach of children

Do not try to repair the faulty unit.

Do not storage flammable or explosive materials in the refrigerators.

If you don't want to use the unit for a while pull out the plug from the mains socket.

Do not cover the ventilation openings of the back of the fan, on the upper part of the refrigerator and the gap below the door.

Before servicing or cleaning the appliance, unplug the appliance from the mains or disconnect the electrical power supply

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard

Relevant for Australia: Supply cord fitted with a plug complies with AS/NZS 3112.

Frost formation on the interior evaporator wall and upper parts is a natural phenomenon. Therefore, the appliance should be defrosted during normal cleaning or maintenance.

Please note that changes to the appliance construction will cancel all warranty and product liability.

Contents

- Warning..... 1
- Technical date 2
- Before using the appliance 3
- Electrical connection 3
- Temperature control 4
- Control and cleaning..... 4
- Warranty, spare parts and service 5
- Disposal 6

Technical date		Net capacity (litres)	39 l
Refrigerant	R 290/50g	Gross capacity (litres)	44,5 l
External dimensions (W * D * H)	700 * 675 * 515	Temperature range °C	-20 ±2 °C
Internal dimensions (W * D * H)	538* 360 * 165	Climatic class	III. (25°C)
Branding surface	0,35m ²	Cooling	Silent
Net weight	34 kg	Voltage	230 V/50 Hz
Gross weight	37 kg	Energy consumption	2.9 kWh/24 h

The technical specifications may change without notice.

Before using the appliance

Please read these instructions carefully. They will give you important information on the installation, operation and maintenance of the appliance.

Damaged appliances must not be connected to the mains. If in doubt, ask your supplier.

Placing

It is best to place the appliance in a dry room with good air circulation. The room temperature should be as low as possible (energy-saving), but not lower than +5°C.

The unit belongs to climate category 3 and may be operated only rooms with a temperature range from +16°C and +25°C.

In placing the appliance, it must not be exposed to direct sunlight or placed up against a heat source

The appliance must be placed on an even, horizontal and stable surface.

If the furnishing of the room allows positioning only close to the heat source, the following minimum clearance of 4 cm must be kept: If the clearance from a gas or electric oven is 25 cm (or less), a 0.5-1.0 cm thick insulating sheet must be inserted between the two units.

Min. 120 cm from oil or coal fired ovens. Not for built in, only free standing.

Minimum free space above appliance 500mm

Starting:

Before using the appliance, it is advisable to wash down the inside with lukewarm water and a mild detergent, and then to dry it thoroughly.

Operate the unit empty for circa 2 or 3 hours after turning on.

The refrigerator filled up with pre-cooled product.

The runtime in the appliance will depend on the temperature of the room.

It may therefore be necessary to change the thermostat setting from time to time.

Electrical connection

Important: Wiring and connections in power supply systems must have all applicable (local and national) electrical codes. Consult these codes lengths and sizes prior to cabinet installation.

This appliance meets the provisions of the following directives: 89/336/EEC (electromagnetic compatibility), 73/23/EEC (electrical equipment designed for use within certain voltage limits) as amended.

The rating plate provides various technical information as well as type and serial number.

Do not under any circumstances cut or remove the round grounding prong from the appliance plug.

Do not under any circumstances use extension cords.

PRODUCT FOR INDOOR USE ONLY

Temperature control

The digital refrigeration controller on the right side controls the temperature. The inside temperature can be adjusted by the digital controller.

The steps of the setting of the requested temperature:

1. Keep pressed the SET key for minimum 2 sec
2. The value of present SET point appears on the display and the °C or °F LED starts to flash
3. To change the value press the [UP] or [DOWN] key in 10 sec
4. To save the modified value press the SET key again and wait for 10 sec

The temperature of the cold chamber can be read from the display of digital controller. The displayed temperature equal with the temperature of the product placed on the load level $\pm 2^{\circ}\text{C}$. This marginally can be bigger in different climate classes. In this case adjust colder or warmer value in the digital controller.

By the setting of temperature note the offered temperature for the store of frozen product.



Control and cleaning

- Before beginning cleaning, switch off main power at the wall socket.
- Clean the appliance with a mild soap liquid.
- Use a wrung-out cloth or sponge.
- Always dry off with a clean, dry cloth.
- It is recommended to remove dust and debris collected on the condenser under the refrigerator once or twice every 3 month. Gently lift the refrigerator.
- Remove dust and other contamination collected below the refrigerator.
- Remove dust collected on the condenser with a brush.
- Attention: always keep the ventilation openings clean.

Warning: Never use cleaning agents containing abrasive substances

Switching off the unit when not in use

- Pull out the plug from the socket.
- Wipe and dry the inner part and open the lid a bit to remove unpleasant odors.



Warranty, spare parts and service

Warranty disclaimer

Faults and damage caused directly or indirectly by incorrect operation, misuse, insufficient maintenance, incorrect building, installation or mains connection. Fire, accident, lightning, voltage variation or other electrical interference, including defective fuses or faults in mains installations are not covered by the warranty.

Repairs performed by others than approved service centers and any other faults and damage that the manufacturer can substantiate are caused by reasons other than manufacturing or material faults are not covered by the warranty.

Please note that changes to the construction of the appliance or changes to the component equipment of the appliance will invalidate warranty and product liability, and the appliance cannot be used lawfully. The approval stated on rating plate will also be invalidated.

Transport damage discovered by the buyer is primarily a matter to be settled between the buyer and the distributor, i.e. the distributor must ensure that such complaints are resolved to the buyer's satisfaction.

Before calling for technical assistance, please check whether you are able to rectify the fault yourself. If your request for assistance is unwarranted, e.g. if the appliance has failed as a result of a blown fuse or incorrect operation, you will be charged the costs incurred by your call for technical assistance.

Spare parts

When ordering spare parts, state the type, serial and production numbers of your appliance. This information is given on the rating plate. The rating plate contains various technical information, type and serial numbers.

Disposal

Information for Users on Collection and Disposal of Old Equipment and used Batteries.



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste. For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points, in accordance with your national legislation and the Directives 2002/96/EC and 2006/66/EC.

By disposing of these products and batteries correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.

For more information about collection and recycling of old products and batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.



For business users in the European Union.

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.

[Information on Disposal in other Countries outside the European Union]

These symbols are only valid in the European Union. If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.



Note for the battery symbol (bottom two symbol examples):

This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the directive for the chemical involved.

Reserves the right to alter specifications without prior notice

FRIGOR - Contact information

Vibocold A/S Phone +45 8661 3411
 Livøvej 22 Fax +45 8661 3764
 DK-8800 Viborg mail@vibocold.dk

